



Read This First

Unloading Photos and Videos

From your HP iPAQ Companion CD, you can install HP Image Transfer which enables automatic unloading of your photos and videos to your PC. Video clips that are larger than 15MB in size will not transfer off your HP iPAQ through ActiveSync. To unload these video clips from your HP iPAQ, you must do it manually. Go to Windows Explorer on your PC, browse Mobile Device, and manually copy or move the video files from your HP iPAQ to your PC.

Playing Video Recordings on Your PC

In addition to taking photos using the built-in HP Photosmart camera, you can also record, save, and view videos with your new HP iPAQ. You can record video clips in MotionJPEG (.avi) or H.263 (.3gp) formats. To play your .3gp video clips on your PC, you will need to download a free version of a media player (such as QuickTime® or RealPlayer®) from the Internet. To get information about these media players, visit the following web sites:

■ <http://www.real.com>

■ <http://www.apple.com/quicktime/download/>

For more information about your built-in HP Photosmart camera's features, refer to the *Special Features Guide* that came with your HP iPAQ or Help files on your HP iPAQ. From the **Launch** Page, tap **Start > Help > HP Photosmart**.

Note: A standard WLAN infrastructure, other Bluetooth-enabled devices, separately purchased equipment and a service contract with a wireless airtime provide may be required for applicable wireless communication. Wireless Internet use requires separately purchased Internet service contract. Check with service provider for availability and coverage in your area. Not all web content available.



375288-B31

© 2004 Hewlett-Packard Development Company, L.P. iPAQ is a trademark of Hewlett-Packard Development Company, L.P. in the U.S. and other countries. Microsoft, Windows, the Windows logo, Outlook, and ActiveSync are trademarks of Microsoft Corporation in the U.S. and other countries.

First Edition, August 2004.

Printed in Taiwan.